

W3150A+/W5100 Errata Sheet

Document History

Ver 1.0.0 (OCT. 27, 2007)	First release (erratum 1)
Ver 2.0.0 (SEP. 10, 2008)	Add W5100 solution for erratum 1
	Remove Recommendation for erratum 1
Ver 2.1 (APR. 5, 2010)	Remove the erratum solution for W5100 in
	v2.0 and bring back the recommendation of
	v1.0
Ver 2.2 (FEB. 17, 2012)	Add erratum 2, 3
Ver 2.3 (MAR. 5, 2012)	Add a solution for erratum 2, 3
Ver 2.4 (OCT. 28, 2013)	Add a description of solution for erratum 2

© 2012 WIZnet Co., Ltd. All Rights Reserved. For more information, visit our website at http://www.wiznet.co.kr



Erratum 1		
Phenomenon	Unable to complete SEND/SENDMAC command in UDP/IP-Raw mode	
	That is, do not assert SEND_OK interrupt and do not equal the values o	
	Socket n Tx Read Pointer Register (Sn_TX_RD) and Socket n Tx Write	
	Pointer Register (Sn_TX_WR).	
Condition	Generally, the Sn_TX_RD value is equal to the Sn_TX_WR value and assert	
	SEND_OK interrupt when a transmission process was completed.	
	But the case of errata which the Sn_TX_RD and Sn_TX_WR values are	
	different and do not assert SEND_OK interrupt in UDP/IP-Raw mode. Thi	
	phenomenon is occurred when our chip receive data in opened socket (i.e	
	assert RECV interrupt) and simultaneously the application program (Hos	
	MCU) executes SEND/SENDMAC command on that socket.	
	NetworkA Subnet mask 255.255.255.0	
	HOST_AB GW_A 10.11.12.4 10.11.0.1	
	HOST_AA 10.11.12.3	
	Figure 1. General network	
	In Figure 1 network,	
	1. Open UDP socket in AA. Port number is 1000.	
	2. Send UDP data packet(destination port number 1000) from AB to	
	AA.	
	3. AA processes the UDP data packet from AB.	
	4. Host MCU in AA runs SEND command to send.	
	When completion of 3 in AA (i.e. AA assert RECV interrupt), AA also runs	
	(i.e. run SEND command). In that case, do not complete process 4 due t	
	errata.	



Solution

In case of W3150A+,

If you can monitor the RXDV signal (in MII interface), you can solve this problem.

Before you execute SEND/SENDMAC command in UDP/IP-Raw mode, check the value of RXDV signal is '0'. That means there is no received data packet, so you can avoid the errata condition.

Refer to following pseudo-code.

```
/* Change sendto() function */
Function sendto()
{
...
While (RXDV == '1');
SEND command;
/* Complete Sending */
}
```

Recommendat ion

In case of W5100,

We don't have solution but we can give a recommendation.

After complete a transmission process, check whether Sn_TX_RD and Sn_TX_WR have same values or not. If both values are still different, close the socket and reset by force.

```
/* Change sendto() function */
Function sendto()
{
...
/* Complete Sending */
    /* wait until Sn_TX_WR and Sn_TX_RD are same */
    While (Sn_TX_WR != Sn_TX_RD)
    {
        wait some time;
        loop_cnt++;
        if (loop_cnt > CONST_BLOCK_CNT) goto RESET
    }
}
```



Erratum 2	The WE400 weekles with material ID - James for the ADD
Phenomenon	The W5100 replies with gateway IP address for the ARP request from
	network node which has "0.0.0.0" IP address. But normally the W510
	should replies with target IP address "0.0.0.0" not the gateway I
	address.
Condition	Normal Node IP: 0.0.0.0 ARP Request W5100/W7100A IP: 192.168.1.2 SN: 255.255.255.0 Wrong TargetIP address: 192.168.1.254 Normally mustbe 0.0.0.0 GW: 192.168.1.254 W5100/W7100A W5100/W7100A GW: 192.168.1.24 W75100/W7100A W75100/W7100A GW: 192.168.1.254 Wrong TargetIP address: 192.168.1.254 Normally mustbe 0.0.0.0 W5100/W7100A W5100/W7100A W5100/W7100A W75100/W7100A W75100/W710A W75100/W710A W75100/W710A W75100/W710A W75100/W710A W75100/W710A
	The main reason of this erratum is subnet calculating logic. The W510
	misunderstands the node locates other sub-network when target ha
	"0.0.0.0" IP address. So the W5100 set the target IP to the gateway I
	instead of "0.0.0.0" and sends the ARP reply.
	To avoid this erratum we must keep the subnet mask register value to zer
	except two cases which are "CONNECT" command in TCP and "SEND
	command in UDP. Because only these two cases are referring the subne
	mask register and sending the ARP request.
	So set the subnet mask register to "0.0.0.0" and keeping it but save the
	right subnet mask value to the global variable when you initialize the W5100
	When you use connect command in TCP or send command in UDP, set the
	subnet mask register to the right value using the variable before executing
	connect or send command. After done connect or send command, clears th
Solution	subnet mask register again to keep its value to "0.0.0.0".
Solution	In the case of applying, you can't use the subnet broadcasting.
	Before applying (without solution) W5100 Initialization Set GW: 192.168.1.254 Set IP: 192.168.1.2 Set SN: 255.255.255.0 TCP Connect Set SN from global variable "Execute connect command" Clear SN: 0.0.0.0 Set SN: 0.0.0.0 UDP Send "Execute send command" Clear SN: 0.0.0.0



```
Example pseudo code:
/* Global variable declaration for subnet mask value */
unsigned char subnet_val[4];
/* W5100 initialization function */
Function Initialize_W5100()
/* Clear the subnet mask register */
   IINCHIP_WRITE(SUBRO, 0);
   IINCHIP_WRITE(SUBR1, 0);
   IINCHIP_WRITE(SUBR2, 0);
   IINCHIP_WRITE(SUBR3, 0);
/* Save the right subnet mask value if the subnet is 255.255.255.0 */
   subnet_val[0] = 255;
   subnet_val[1] = 255;
   subnet_val[2] = 255;
   subnet_val[3] = 0;
/* TCP connect function */
Function TCP_Connect()
/* Set the subnet mask register to the right value using the variable */
   IINCHIP_WRITE(SUBRO, subnet_val[0]);
   IINCHIP_WRITE(SUBR1, subnet_val[1]);
   IINCHIP_WRITE(SUBR2, subnet_val[2]);
   IINCHIP_WRITE(SUBR3, subnet_val[3]);
 * Execute TCP connect command */
   IINCHIP_WRITE(Sn_CR(socket), Sn_CR_CONNECT);
/* Wait for command done */
   while(Sn_CR(socket));
/* Clear the subnet mask register again and keep it */
   IINCHIP_WRITE(SUBRO, 0);
   IINCHIP_WRITE(SUBR1, 0);
```



```
IINCHIP_WRITE(SUBR2, 0);
  IINCHIP_WRITE(SUBR3, 0);
/* UDP sendto function */
Function UDP_Sendto()
/* Set the subnet mask register to the right value using the variable */
  IINCHIP_WRITE(SUBR0, subnet_val[0]);
  IINCHIP_WRITE(SUBR1, subnet_val[1]);
  IINCHIP_WRITE(SUBR2, subnet_val[2]);
  IINCHIP_WRITE(SUBR3, subnet_val[3]);
* Execute UDP send command */
  IINCHIP_WRITE(Sn_CR(socket), Sn_CR_SEND);
/* Wait for command done */
  while(Sn_CR(socket));
/* Clear the subnet mask register again and keep it */
  IINCHIP_WRITE(SUBR0, 0);
  IINCHIP_WRITE(SUBR1, 0);
  IINCHIP_WRITE(SUBR2, 0);
  IINCHIP_WRITE(SUBR3, 0);
```



Erratum 3	
Phenomenon	Assuming that the IP address of W5100 is "0.0.0.0" and the gateway, subnet mask is valid (not "0.0.0.0"), the W5100 set the target IP address of ARP request to the gateway IP address not the target node IP address when sends ARP request to another node. So the peer node cannot receive the ARP request from the W5100.
Condition	Normal Node IP: 192.168.1.3 SN: 255.255.255.0 GW: 192.168.1.254 The W5100 miss calculates the sub-network location when sends the ARP request if its own IP address is "0.0.0.0". In the same condition, even if the gateway IP address is "0.0.0.0", the W5100 sends ARP request to "0.0.0.0" IP address because the W5100 sends ARP request to the gateway.
Solution	The reason of this erratum3 is same as erratum2 so the solution is also same with erratum2. Please refer to the solution of erratum2.